

Attaching The Evacuator II In-Line Control Valve

NOTE: Install the in-line control valve to ensure it remains dry.

- 1. Carefully cut and remove about two feet of blue plastic jacket from hose bundle.**
- 2. Connect 1/2" o.d. tubing from filter/regulator assembly to hose barb marked "air in".**
- 3. Connect 1/2" o.d. tubing from hose barb marked "to pump" to hose barb on pump head.**
- 4. Connect 1/8" o.d. black logic line from black fitting on pump to black fitting on in-line valve.**
- 5. Connect 1/8" o.d. green logic line from green fitting on pump to green fitting on in-line valve.**
- 6. Connect 1/8" o.d. blue line to blue pump fitting. This line does not connect to in-line valve. It should be left to exhaust above the water table.**
- 7. Connect 5/8" o.d. fluid discharge line to hose barb on pump.**
- 8. Be sure to attach a strain relief cable to eye bolt on pump to prevent tension on the pump lines.**